05IE6–01

PROBLEM SYMPTOMS TABLE

Symptoms	Suspected Area	See Page
Power mode does not change to ON (IG and ACC)	• Power source control ECU • AM1 fuse • AM2 fuse • Power switch • Key slot • Wire harness	05–2175
Power mode does not change to ON (ACC)	• Power source control ECU • AM1 fuse • AM2 fuse • ACC Relay • Wire harness	05–2182
Power mode does not change to ON (IG)	• Power source control ECU • AM1 fuse • AM2 fuse • IG1 relay • IG2 relay • Wire harness	05–2187
Power mode does not change to ON (READY)	• Power source control ECU • Stop lamp switch assy • Wire harness	05–2193