05ICH–01

PROBLEM SYMPTOMS TABLE

Proceed to the reference page shown in the table below for each malfunction symptom and troubleshoot each circuit.

HINT:

The theft deterrent system is based on the premise that the power door lock control system and the wireless door lock control system are operating normally. Check these systems first before troubleshooting the theft deterrent system.

Symptom	Suspected Area	See Page
Theft deterrent system cannot be set*	1. Theft warning sensor cancel switch circuit 2. Security indicator circuit 3. ECU power source circuit 4. Unlock warning switch circuit 5. Door key lock and unlock switch 6. Door courtesy switch circuit 7. Back door courtesy switch circuit 8. Engine hood courtesy switch circuit 9. Theft warning ECU	05–2224 05–2221 05–2216 05–2039 05–1□79 05–1□79 05–1□79 05–2232 –
Security indicator does not blink when theft deterrent system is set*	1. Security indicator circuit 2. Theft warning ECU	05–2221 05–2216
Alarm sounding state cannot be canceled even when key is inserted into key slot, hybrid system is started and acceleration pedal is pushed for 10 seconds	1. Ignition circuit 2. Unlock warning switch circuit 3. Theft warning ECU	05–2218 05–2034 –
Theft deterrent system can be set even when door is open	1. Door courtesy switch circuit 2. Theft warning ECU	05–1□79 –
Horns (low pitched, high pitched) do not sound while theft deterrent system is in warning operation	1. Horn (low pitched, high pitched) circuit 2. Horn assy 3. Theft warning ECU	05–2235 77–4 –
Hazard warning lamps do not flash while theft deterrent system is in warning operation	1. Hazard warning circuit 2. Theft warning ECU	65–1□ –
Room lamp does not illuminate while theft deterrent system is in warning operation	1. Room lamp circuit 2. Theft warning ECU	65–1□ –
Self–power siren does not sound while theft deterrent system is in warning operation	1. Theft warning siren circuit 2. Theft warning ECU	05–2229 –
Hazard warning lamps flash even when theft deterrent system is not set	1. Hazard warning switch circuit 2. Theft warning ECU	65–1□ –
Room lamp illuminates even when theft deterrent system is not set	1. Room lamp circuit 2. Theft warning ECU	65–1□ –
Intrusion sensor operates even when theft deterrent system is not set*	1. Intrusion sensor circuit 2. Theft warning ECU	05–2224 –
Theft deterrent system operates when intrusion sensor cancel switch is OFF	1. Intrusion sensor cancel switch circuit 2. Theft warning ECU	05–2227 –
Intrusion sensor does not operate while theft deterrent system is in warning operation*	1. Intrusion sensor circuit 2. Theft warning ECU	05–2224 –

HINT:

*: For these symptoms, if the suspected areas are found to be functioning normally, replace the instrument panel J/B.