05IJH–01

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during DTC check, check the circuit corresponding to the code in the table below. Proceed to the page given for the circuit.

DTC No. (See Page)	Detection Item	Trouble Area
B1200 (05–2262)	Body ECU communication stop	• Wire harness • Body ECU
B1207*1 (05–2266)	Smart ECU communication stop	• Wire harness • Smart ECU
B1210 (05–2270)	Power source control ECU communication stop	• Wire harness • Power source control ECU
B1214, B1215 (05–2274)	• Door system communication bus malfunction (+B short) • Door system communication bus malfunction (GND short)	• Wire harness • ECU (Door system bus)
B1248 (05–2282)	AVC–LAN communication impossible	• Wire harness • ECUs (AVC–LAN system bus)
B1260 (05–2284)	Transmission control ECU communication stop	• Wire harness • Transmission control ECU
B1262 (05–2288)	A/C ECU communication stop	• Wire harness • A/C ECU
B1269*2 (05–2292)	Theft deterrent ECU communication stop	• Wire harness • Theft deterrent ECU
B1271 (05–2296)	Combination meter ECU communication stop	• Wire harness • Combination meter ECU
B1294 (05–2300)	Immobilizer ECU communication stop	• Wire harness • Transponder key ECU

*1: w/ Smart entry system

*2: w/ Theft deterrent system

HINT:

When "+B or GND short malfunction of communication bus" DTCs (B1214, B1215, etc.) are detected at the same time as "communication stop" DTCs (B1211, B1212, etc.), please repair the "+B or GND short malfunction of communication bus" DTCs first.