610JK–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Driver side seat belt warning lamp does not blink	1. DOME fuse	61–1
	2. GAUGE fuse	61–1
	3. Front seat inner belt assy (driver side)	61–7
	4. Combination meter	05–1709
	5. Wire harness	–
Driver side seat belt warning lamp does not illuminate	1. Front seat inner belt assy (driver side)	61–7
	2. Combination meter	05–1709
	3. Wire harness	–
Passenger side seat belt warning lamp does not blink	1. DOME fuse	61–1
	2. GAUGE fuse	61–1
	3. Front seat inner belt assy (passenger side)	61–7
	4. Occupant detection sensor	61–7
	5. Combination meter	05–1711
	6. Wire harness	–
Passenger side seat belt warning lamp does not illuminate	1. Front seat inner belt assy (passenger side)	61–7
	2. Combination meter	05–1711
	3. Wire harness	–