65114–01

OPERATION CHECK

1. ILLUMINATED ENTRY OPERATION CHECK

(a) Illumination entry system controls the following:
- Key slot lamp
- Room lamp assy No.1

(b) Check that the lamps come on after:
(1) Unlocking driver or front passenger door that was closed and locked with the power switch off.

(c) Check that the lamps fade out after:
(1) Leaving the doors unlocked for 15 seconds.
(2) Turning the power switch on (ACC or IG).
(3) Locking all the doors.

(d) Check that the lamps stay on for at least 15 seconds after opening any of the doors, then fade out again after 15 seconds.

(e) Check that the lamps come on after:
(1) Closing all the doors and turning the power switch off from on (ACC or IG).

(f) Check that the lamps fade out after:
(1) Leaving the doors unlocked for 15 seconds.
(2) Turning the power switch on (ACC or IG).
(3) Locking all the doors.

(g) Check that the lamps stay on for at least 15 seconds after opening any of the doors, then fade out again in 15 seconds after closing all the doors.

(h) Check that the lamps come on when opening any of the doors and fade out after either closing and locking them or turning the power switch on (ACC or IG).

2. LIGHT AUTO TURN OFF SYSTEM OPERATION CHECK (EUROPE)

(a) Turn the power switch on (IG), and switch the light control switch into the TAIL position when driver side door is closed.

(b) Turn the power switch off. Check that the front fog lamp goes off.

(c) Turn the power switch on (IG), and switch the light control switch into the HEAD position when driver side door is closed.

(d) Turn the power switch off. Check that the headlamp and front fog lamps go off.

3. LIGHT AUTO TURN OFF SYSTEM OPERATION CHECK (AUSTRALIA)

(a) Turn the power switch on (IG), and switch the light control switch into the TAIL or HEAD position and front fog lamp switch is in the ON position when driver side door is closed.

(b) Turn the power switch off and open the driver side door. Check that the headlamp, taillamp and front fog lamps go off.

4. BATTERY SAVER OPERATION CHECK

(a) Check that the all lamps go off after approximately 20 minutes with the power switch off and driver door is opened.

5. DAYTIME RUNNING LIGHT OPERATION CHECK (EUROPE)

(a) Check that the headlamp comes on when the light control switch is off, the power switch is ON (IG), and the vehicle is ready to run.

(b) Check that the headlamp goes off when the power switch is turned off.