65116–01

PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.
HINT:
Inspect each malfunction circuit in numerical order for the corresponding symptom.
If the malfunction still exist even after checking and confirming that all the circuit are normal, replace the ECU.

1. HEADLAMP AND TAIL LAMP SYSTEM

Symptoms	Suspected Area	See page
Low beam does not come on (one side).	1. H–LP LH/H–LP RH fuse 2. Bulb 3. Wire harness or connector	– – –
Low beam does not come on (both sides).	1. HEAD MAIN fuse 2. Headlamp dimmer switch 3. Wire harness or connector 4. Multiplex Network Body ECU	– 65–20 – –
High beam does not come on (one side).	1. H–LP LH/H–LP RH fuse 2. Bulb 3. Wire harness or connector	– – –
High beam does not come on (both sides).	1. HEAD MAIN fuse 2. Headlamp dimmer switch 3. Wire harness or connector 4. Multiplex Network Body ECU	– 65–20 – –
FLASH does not come on (Low beam and high beam are normal).	1. Headlamp dimmer switch 2. Wire harness or connector 3. Multiplex Network Body ECU	65–20 – –
Headlamp is dim.	1. Bulb 2. Wire harness or connector	– –
Taillamp does not come on (all).	1. Headlamp dimmer switch 2. Wire harness or connector 3. Multiplex Network Body ECU	65–20 – –
One taillamp does not come on.	1. Bulb 2. Wire harness or connector	– –
Daytime running light system does not operate.	1. Headlamp dimmer switch 2. Wire harness or connector 3. Multiplex Network Body ECU	65–20 – –

2. LIGHT AUTO TURN OFF SYSTEM

Symptoms	Suspected Area	See page
Light auto turn off system does not operate.	1. Headlamp dimmer switch 2. Door courtesy switch (Australia) 3. Wire harness or connector 4. Multiplex Network Body ECU	65–20 65–20 – –

3. FOG LAMP SYSTEM

Symptoms	Suspected Area	See page
Front fog lamp does not come on (one side).	1. Bulb 2. Wire harness or connector	– –
Front fog lamp does not come on (both sides).	1. FR FOG fuse 2. FR FOG relay 3. Headlamp dimmer switch 4. Wire harness or connector 5. Multiplex Network Body ECU	– – 65–20 – –
Rear fog lamp does not come on (one side).	1. Bulb 2. Wire harness or connector	– –
Rear fog lamp does not come on (both sides).	1. RR FOG fuse 2. RR FOG relay 3. Headlamp dimmer switch 4. Wire harness or connector 5. Multiplex Network Body ECU	– – 65–20 – –

4. TURN SIGNAL LAMP AND HAZARD WARNING SYSTEM

Symptoms	Suspected Area	See page
”Hazard” and ”Turn” do not come on.	1. HAZ/GAUGE fuse 2. Turn signal flasher relay 3. Wire harness or connector 4. Instrument panel junction block assy	– 65–17 – –
Hazard warning light does not come on (”Turn” is normal).	1. Hazard warning switch 2. Wire harness or connector 3. Instrument panel junction block assy	65–20 – –
Turn signal does not come on (”Hazard” is normal).	1. Headlamp dimmer switch 2. Wire harness or connector 3. Instrument panel junction block assy	65–20 – –
Turn signal does not come on in one direction.	1. Bulb 2. Wire harness or connector 3. Instrument panel junction block assy	– – –

5. STOP LIGHT SYSTEM

Symptoms	Suspected Area	See page
One stop lamp does not come on.	1. Bulb 2. Wire harness or connector	– –
Stop lamp does not come on (all).	1. STOP fuse 2. Stop light switch assy 3. Wire harness or connector	– 65–20 –

6. ILLUMINATED ENTRY SYSTEM

Symptoms	Suspected Area	See page
Illuminated entry system controlled by the multiplex network body ECU does not operate.	1. Door courtesy switch 2. Door unlock detection switch 3. Wire harness or connector 4. Multiplex Network Body ECU	65–20 05–1776 – –

7. HEADLIGHT BEAM LEVEL CONTROL SYSTEM

Symptoms	Suspected Area	See page
Headlamp beam level control system does not operate (one side).	1. Headlamp leveling switch 2. Headlamp assy (Headlight beam level control actuator) 3. Wire harness or connector	65–20 65–17 –
Headlamp beam level control system does not operate (both sides).	1. TAIL fuse 2. Headlamp leveling switch 3. Headlamp assy (Headlight beam level control actuator) 4. Wire harness or connector	– 65–20 65–17 –

8. OTHERS

Symptoms	Suspected Area	See page
Vanity lamp does not come on.	1. DOME fuse 2. Bulb 3. Wire harness or connector	– – –
Back up lamp does not come on.	1. GAUGE fuse 2. IG 1 relay 3. Bulb 4. Back/up relay 5. Wire harness or connector	– – – 65–20 –
Luggage room lamp does not come on.	1. DOME fuse 2. Bulb 3. Wire harness or connector	– – –
Courtesy lamp does not come on.	1. DOME fuse 2. Bulb 3. Courtesy lamp switch 4. Wire harness or connector 5. Multiplex Network Body ECU	– – 65–20 – –