70127–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Rear window defogger does not operate (Indicator ON)	1. DEFOG H–fuse	70–36
	2. A/C (HTR) fuse	70–36
	3. GAUGE fuse	70–36
	4. DOME fuse	70–36
	5. ECU–B fuse	70–36
	6. DEF relay	70–42
	7. Rear window defogger wire	70–42
	8. Wire harness	–
Rear window defogger does not operate (Indicator OFF)	1. DEFOG H–fuse	70–36
	2. A/C (HTR) fuse	70–36
	3. GAUGE fuse	70–36
	4. DOME fuse	70–36
	5. ECU–B fuse	70–36
	6. DEF relay	70–42
	7. Combination meter	05–1035
	8. Steering wheel pad switch	70–42
	9. Multi–display assy	05–1035
	10.Rear window defogger wire	70–42
	11.Wire harness	–
Mirror heater does not operate (Indicator ON)	1. M/HTR fuse	70–36
	2. A/C (HTR) fuse	70–36
	3. GAUGE fuse	70–36
	4. DOME fuse	70–36
	5. ECU–B fuse	70–36
	6. Mirror heater relay	70–42
	7. Outer rear view mirror assy	70–42
	8. Wire harness	–
Mirror heater does not operate (Indicator OFF)	1. M/HTR fuse	70–36
	2. A/C (HTR) fuse	70–36
	3. GAUGE fuse	70–36
	4. DOME fuse	70–36
	5. ECU–B fuse	70–36
	6. Mirror heater relay	70–42
	7. Combination meter	05–1035
	8. Steering wheel pad switch	70–42
	9. Multi–display assy	05–1035
	10.Outer rear view mirror assy	70–42
	11.Wire harness	–

HINT:

The window defogger system is part of the large–scale multiplex communication system. This system features shared communication wiring that reduces the wiring complexity of the communication lines. The first step in any repair is to confirm the proper operation of the communication system. Proceed with troubleshooting after the communication has been verified (see Multiplex Communication System).