7700O–01

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Horn does not sound.	1. HORN fuse	77–4
	2. HORN relay	77–4
	3. High pitched horn	77–4
	4. Low pitched horn	77–4
	5. Horn button switch	–
	6. Wire harness	–