ELECTRICAL KEY HOLDER ASSY

8005L–01

REPLACEMENT

HINT:

- The installation procedures are the removal procedures in reverse order. However, only installation procedures requiring additional information are included.
- A bolt without a torque specification is shown in the standard bolt chart (see page 03–2).

1. DISCONNECT BATTERY NEGATIVE TERMINAL

2. REMOVE INSTRUMENT PANEL FINISH PANEL SUB–ASSY LOWER (See page 71–13)

3. REMOVE ELECTRICAL KEY HOLDER ASSY

(a) Disconnect the connector.

(b) Remove the 2 screws and electrical key holder.

4. CONNECT BATTERY NEGATIVE TERMINAL

NOTICE:

When disconnecting the negative (–) battery terminal, initialize the following systems after the terminal is reconnected.

5. SYSTEM INITIALIZE (See page 01–29)

System Name	See Page
Power Window Control System	01–29