POWER SWITCH

REPLACEMENT

8005S–01

HINT:

- The installation procedures are the removal procedures in reverse order. However, only installation procedures requiring additional information are included.
- A bolt without a torque specification is shown in the standard bolt chart (see page 03–2).

1. DISCONNECT BATTERY NEGATIVE TERMINAL

2. LHD models:
REMOVE INSTRUMENT PANEL FINISH PANEL SUB–ASSY UPPER (See page 71–13)

3. RHD models:
REMOVE INSTRUMENT PANEL REGISTER ASSY NO.1 (See page 71–13)

4. REMOVE POWER SWITCH

(a) Disconnect the connector.

(b) Disengage the 2 clips and remove the power switch.

5. CONNECT BATTERY NEGATIVE TERMINAL

NOTICE:

When disconnecting the negative (–) battery terminal, initialize the following systems after the terminal is reconnected.

6. SYSTEM INITIALIZE

System Name	See Page
Power Window Control System	01–29