SMART KEY ECU

REPLACEMENT

8005T–01

HINT:

- The installation procedures are the removal procedures in reverse order. However, only installation procedures requiring additional information are included.
- A bolt without a torque specification is shown in the standard bolt chart (see page 03–2).

1. DISCONNECT BATTERY NEGATIVE TERMINAL

2. REMOVE INSTRUMENT PANEL FINISH PANEL SUB–ASSY UPPER (See page 71–7)

3. REMOVE SMART KEY ECU

(a) Disconnect the connector.

(b) Remove the 2 screws and smart key ECU.

4. CONNECT BATTERY NEGATIVE TERMINAL

NOTICE:

When disconnecting the negative (–) battery terminal, initialize the following systems after the terminal is reconnected.

5. SYSTEM INITIALIZE

System Name	See Page
Power Window Control System	01–29