ROOF PANEL (ASSY): w/ Sliding Roof (Short Body)



F24735A


Symbol meaning

REMOVAL : Remove Weld Points

INSTALLATION : MIG Plug Weld : Spot Weld : Body Sealer

F24735B

REMOVAL·INSTALLATION



F24735

REMOVAL POINT

1 If reusing the roof panel reinforcement, trim the hemming location using a disc sander, etc.

INSTALLATION POINT

1 Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.

2 Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)

3 After welding, apply body sealer to the corresponding parts. (See the paint·coating)


4 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.


Symbol meaning

REMOVAL : Remove Weld Points

INSTALLATION : MIG Plug Weld : Spot Weld : Body Sealer

F24736B





F24736

INSTALLATION POINT

1 Before temporarily installing the new parts, apply body sealer to the windshield header panel, roof panel reinforcement and back door opening frame.
HINT:
1) Apply just enough sealer for the new parts to make contact.

2 Bend the flange hem with a wooden hammer and dolly.
HINT:
1) Perform hemming three steps, being careful not to warp the panel.