## ■CUSTOMIZED BODY ELECTRONICS FUNCTION

A Techstream can be used to customize the system settings.

| System | Techstream Display Content | Contents | Default Setting | Available Setting |
|---|---|---|---|---|
| Lighting | Foot Light | Changes illumination duration after door closure. | 30 sec | 7.5 sec/ 15 sec/ 30 sec/ OFF |
| | Lighting Time | Changes illumination duration after door closure. (It will quickly fade out when turning ignition switch ON.) | 15 sec | 7.5 sec/ 15 sec/ 30 sec |
| | I/L ON W/Door Key Unlock | Function to light up room light when unlocking with door key cylinder. (Room light illuminated when interior light switch set to DOOR) | ON | ON/OFF |
| | I/L when ACC OFF | Illuminates light when ignition switch turned to ACC. (Room light illuminated when interior light switch set to DOOR) | ON | ON/OFF |
| | Light Auto OFF Delay | Function to continue illuminating headlight for certain period of time after closing all doors with ignition switch turned from ON to OFF under condition that light control switch is at HEAD or AUTO with the headlight ON. | 30 sec | OFF/ 30 sec/ 60 sec/ 90 sec |
| | Sensitivity* | Function to adjust sensitivity of lighting illumination. | NORMAL | LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2 |
| | Disp EX ON Sen | Changes brightness when lowering lights such as combination meter indicator light, A/C indicator light, and clock light | NORMAL | LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2 |
| | Disp EX OFF Sen | Changes brightness when canceling lowering lights such as combination meter indicator light, A/C indicator light, and clock light. | NORMAL | LIGHT 2/ LIGHT 1/ NORMAL/ DARK 1/ DARK 2 |
| Meter | Key Remind Volume | To change volume of key reminder buzzer. | LARGE | LARGE/ MEDIUM/ SMALL |
| | Key Remind Sound | To change frequency of key reminder buzzer. | SLOW | NORMAL/ FAST/ SLOW |
| | Driver Side Seatbelt Warning Buzzer | To change setting of driver side seat belt warning buzzer. | ON | ON/OFF |
| | Front Passenger Side Seatbelt Warning Buzzer | To change setting of front passenger side seat belt warning buzzer. | ON | ON/OFF |

*: The sensitivity adjustment may be difficult to confirm. Check by driving the customer's vehicle.

(Continued)

| System | Techstream Display Content | Contents | Default Setting | Available Setting |
|---|---|---|---|---|
| A/C | Set Temperature Shift | Function to control the shifted temperature in relation to the displayed temperature. | NORMAL | +2°C/ +1°C/ NORMAL/ –1°C/ –2°C |
| | Air Inlet Mode | In case of turning the A/C ON to cool down the cabin quickly, this is the function to change the mode automatically to RECIRCULATION mode. | AUTO | MANUAL/ AUTO |
| | Compressor Mode | Function to turn the A/C ON automatically by pressing the AUTO button when the blower is ON and the A/C is OFF. | AUTO | MANUAL/ AUTO |
| | Compressor/Air Inlet DEF Operation | Function to turn the A/C ON automatically linked with the FRONT DEF button when A/C is OFF. | LINK | NORMAL/ LINK |
| | Foot/DEF Auto Mode | Function to turn the airflow from FOOT/DEF ON automatically when AUTO MODE is ON. | ON | ON/OFF |
| | Foot/DEF Automatic Blow Up Function | Function to change the blower level automatically when the defroster is ON. | ON | ON/OFF |
| | Ambient Temperature Shift | Function to control the shifted ambient temperature in relation to the displayed ambient temperature. | NORMAL | +3°C/ +2°C/ +1°C/ NORMAL/ –1°C/ –2°C/ –3°C |
| Wiper | Linked Rear Wiper Washer | Function to make the rear wiper run automatically after the washer function is used. | ON | ON/OFF |
| | Rewipe Function | Function to make the rear wiper run once automatically a certain amount of time after the washer function is completed, to prevent the dripping of washing fluid. | ON | ON/OFF |
| Door Lock | Unlock Key Twice | Function that unlocks only driver side door when driver side door key cylinder is turned to UNLOCK once, and unlock all doors when it is turned to UNLOCK twice. For OFF setting, turning it once unlocks all doors. | ON | ON/OFF |
| | Auto Lock | Function that locks all doors when vehicle speed reaches a certain level. | ON | ON/OFF |
| | Auto Lock/Shift | Function that locks all doors when shift lever is moved to P from any other position with engine running and all doors closed. | OFF | ON/OFF |
| | Auto Unlock/Shift | Function that unlocks all doors when shift lever is moved to P from any other position while the ignition switch to ON. | ON | ON/OFF |
| | All Unlock /Open-Close | Function that unlocks all doors when opening driver door within 10 seconds after turning the ignition switch to ON. | OFF | ON/OFF |

(Continued)

| System | Techstream Display Content | Contents | Default Setting | Available Setting |
|---|---|---|---|---|
| Wireless Door Lock | Wireless Control | ON/OFF of wireless door lock function. | ON | ON/OFF |
| | Hazard Answer Back | When lock switch on transmitter pressed, all hazard warning lights illuminate once. When unlock switch pressed, all hazard warning lights illuminate twice. | ON | ON/OFF |
| | Wireless Buzzer Resp | Function that makes wireless buzzer sound for answer back when transmitter lock/unlock switch pressed. | ON | ON/OFF |
| | Open Door Warning | If door is not completely closed and transmitter lock switch is pressed, this function sounds a buzzer for 10 seconds. | ON | ON/OFF |
| | Unlock 2 Operation | Function that unlocks driver side door when unlock switch on transmitter is pressed once, and unlocks all doors when pressed twice. It setting is OFF, pressing unlock switch once makes all doors unlock. | ON | ON/OFF |
| | Auto Lock Time | This function controls amount of time from unlocking doors to automatic re-locking function. | 60 sec | OFF/<br>30 sec/<br>60 sec/<br>120 sec/ |
| | Panic Function | This function operates the theft deterrent system when panic is pressed and held for 0.8 second or more. | ON | ON/OFF |
| Power Back Door | PBD SW Operation | Function that turns power back door closer switch ON when switch is pushed once or held down for 0.8 sec. | 0.8 sec | 0.8 sec/ON |
| | PBD Buzzer | This function makes the power back door buzzer sound when power back door is operating. | ON | ON/OFF |
| | Wirels PBD SW Operation | Function that operates power back door when transmitter switch is pressed in specified way. | 0.8 sec | 1 Oper/<br>2 Oper/<br>0.8 sec/<br>OFF/<br>1 Motion |

(Continued)

| System | Techstream Display Content | Contents | Default Setting | Available Setting |
|---|---|---|---|---|
| Power Window | Door Key P/W Up | Function that raises the drier and passenger power windows when, with the ignition switch off, a key is used to hold the driver door key cylinder to the lock position for more than 2.3 seconds. | ON | ON/OFF |
| | Door Key P/W Down | Function that lowers the drier and passenger power windows when, with the ignition switch off, a key is used to hold the driver door key cylinder to the unlock position for more than 2.3 seconds. | ON | ON/OFF |
| | Door Key Linked Back P/W Up | Function that raises the back door power window when, with the ignition switch off, a key is used to hold the driver door key cylinder to the lock position for more than 0.7 seconds. | ON | ON/OFF |
| | Door Key Linked Back P/W Down | Function that lowers the back door power window when, with the ignition switch off, a key is used to hold the driver door key cylinder to the unlock position for more than 0.7 seconds. | ON | ON/OFF |
| Theft Deterrent | Warning by Glass Breakage Sensor* | Function that turns the glass breakage sensor ON/OFF. This function is only effective for vehicles with glass breakage sensor. | ON | ON/OFF |
| | Warning by Horn | Function that allows the vehicle horn and theft deterrent horn to be used as warning devices. | ON | ON/OFF |
| | Passive Mode (Security system) | PASSIVE MODE is the function used to set the theft deterrent system automatically 30 seconds after closing the driver's door when the door was opened after removing the key from the key cylinder. | OFF | ON/OFF |
| | Entry Delay | Function that changes entry delay time (time before warning starts) for passive mode. | 14 sec | 0 sec/ 14 sec/ 30 sec/ |
| Tilt & Telescopic | Autoaway/Return Function | ON/OFF of the auto away/return function. | ON | ON/OFF |
| Sliding Roof | Door Key Related Operation | Function to select either tilt up or slide open for the manual sliding roof operation linked with power window, witch is activated by holding the driver door key in the unlock position for 3 seconds or more when the ignition switch is off. | SLIDE | TILT/ SLIDE |
| | Door Key Related Open | Function to manually open the sliding roof linked with power window by holding the driver door key in the unlock position for 3 seconds or more when the ignition switch is off. | ON | ON/OFF |
| | Door Key Related Close | Function to manually close the sliding roof linked with power window by holding the driver door key in the lock position for 3 seconds or more when ignition switch is off. | ON | ON/OFF |

*: Models with Glass Breakage Sensor