
REAR VIEW MONITOR SYSTEM

■ DESCRIPTION

To assist the driver in parking the vehicle by monitoring the area behind it, the rear view monitor system has a television camera mounted on the back door. A view of the area behind the vehicle will be displayed on the navigation with AV system.

- The rear view monitor system is available as optional equipment on the models equipped with navigation with AV system.
- This system consists of the television camera and the navigation receiver assembly.

■ SYSTEM DIAGRAM



04E0BE55C

This system operates when all the conditions given below have been met.

- Ignition switch is ON.
- The shift lever is shifted to R.

If the driver moves the shift lever to a position other than R, or switches the mode on the navigation receiver assembly, the display of the area behind the vehicle will stop and change to the display of another mode.

CAUTION

- Do not rely entirely on the rear view monitor system. Use caution, just as you would when backing up any vehicle.
- Never back up while looking only at the screen. The image on the screen may differ from actual conditions. If you back up while looking only at the screen, you may hit an object or have an accident. When backing up, be sure to check by looking behind and all around the vehicle, both directly and using the mirrors, before reversing.