TIRE PRESSURE WARNING SYSTEM

■ DESCRIPTION

- When the tire pressure warning system detects that the pressure of a tire becomes lower than the threshold, it will turn ON the tire pressure warning light to warn the driver.
- The tire pressure warning antenna and receiver receives the tire pressure, temperature, and ID code information from the 4 tire pressure warning valve and transmitters and transmits this information to the tire pressure warning ECU.
- The tire pressure warning ECU monitors the tire pressure warning valve and transmitters to detect the low tire pressure of 4 tires except for spare.

▶ System Diagram ◀

