■ TIRE PRESSURE WARNING SYSTEM OPERATION PRECAUTIONS

The system will be disabled in the following conditions:
(When the condition becomes normal, the system will work properly.)

- If tires not equipped with the tire pressure warning valve and transmitters are used.
- If the ID code on the tire pressure warning valve and transmitters are not registered in the tire pressure warning ECU.
- If the tire pressure warning valve and transmitter battery voltage drops. (Battery life: 10 years)

The system may be disabled in the following conditions:
(When the condition becomes normal, the system will work properly.)

- If electronic devices or facilities using similar radio wave frequencies are nearby.
- If a radio set at similar frequencies is in use in the vehicle.
- If a window tint that affects the radio wave signals is installed.
- If there is a lot of snow or ice on the vehicle, in particular around the wheels or wheel housings.
- If non-genuine wheels are used.
- If tire chains are used.

NOTE:

When the system returns to normal, the tire pressure warning light will go OFF.