■ CUSTOMIZED BODY ELECTRONICS SYSTEM

The intelligent tester II can be used to customize the system settings.

System	Intelligent Tester II Display Content	Content	Default Setting	Available Setting
Lighting	Foot Light	Changes illumination duration after door closure.	30 sec	7.5 sec, 15 sec, 30 sec or OFF
	Lighting Time	Changes illumination duration after door closure (it will quickly fade out when turning ignition switch ON).	15 sec	7.5 sec, 15 sec or 30 sec
	I/L ON W/Door Key Unlock	Function to light up room light when unlocking with door key cylinder (room light illuminates when interior light switch set to DOOR).	ON	ON or OFF
	I/L when ACC OFF	Illuminates light when ignition switch turned to ACC (room light illuminates when interior light switch set to DOOR).	ON	ON or OFF
	Sensitivity*	Function to adjust sensitivity of lighting illumination.	NORMAL	LIGHT 2, LIGHT 1, NORMAL, DARK 1 or DARK 2
	Disp EX ON Sen	Changes brightness when lowering lights such as combination meter indicator light, A/C indicator light, and clock light.	NORMAL	LIGHT 2, LIGHT 1, NORMAL, DARK 1 or DARK 2
	Disp EX OFF Sen	Changes brightness when canceling lowering lights such as combination meter indicator light, A/C indicator light, and clock light.	NORMAL	LIGHT 2, LIGHT 1, NORMAL, DARK 1 or DARK 2
Meter	Key Remind Volume	To change volume of key reminder buzzer.	LARGE	LARGE, MEDIUM or SMALL
	Key Remind Sound	To change frequency of key reminder buzzer.	SLOW	NORMAL, FAST or SLOW
	Driver Side Seatbelt Warning Buzzer	To change setting of driver side seat belt warning buzzer.	ON	ON or OFF
	Front Passenger Side Seatbelt Warning Buzzer	To change setting of front passenger side seat belt warning buzzer.	ON	ON or OFF

*: The sensitivity adjustment may be difficult to confirm. Check by driving the customer's vehicle.

(Continued)

System	Intelligent Tester II Display Content	Content	Default Setting	Available Setting
A/C	Set Temperature Shift	Function to control the shifted temperature in relation to the displayed temperature.	NORMAL	+2°C, +1°C, NORMAL, –1°C or –2°C
	Air Inlet Mode	In case of turning the A/C ON to cool down the cabin quickly, this is the function to change the mode automatically to RECIRCULATION mode.	AUTO	MANUAL or AUTO
	Compressor Mode	Function to turn the A/C ON automatically by pressing the AUTO button when the blower is ON and the A/C is OFF.	AUTO	MANUAL or AUTO
	Compressor/Air Inlet DEF Operation	Function to turn the A/C ON automatically linked with the FRONT DEF button when A/C is OFF.	LINK	NORMAL or LINK
	Foot/DEF Auto Mode	Function to turn the airflow from FOOT/DEF ON automatically when AUTO MODE is ON.	ON	ON or OFF
	Foot/DEF Automatic Blow Up Function	Function to change the blower level automatically when the defroster is ON.	ON	ON or OFF
	Ambient Temperature Shift	Function to control the shifted ambient temperature in relation to the displayed ambient temperature.	NORMAL	+3°C, +2°C, +1°C, NORMAL, –1°C, –2°C or –3°C
Wiper	Linked Rear Wiper Washer	Function to make the rear wiper run automatically after the washer function is used.	ON	ON or OFF
	Rewipe Function	Function to make the rear wiper run once automatically a certain amount of time after the washer function is completed, to prevent the dripping of washing fluid.	ON	ON or OFF
Door Lock	Auto Lock	Function that locks all doors when vehicle speed reaches a certain level.	ON	ON or OFF
	Auto Lock/Shift	Function that locks all doors when the shift lever is moved to P from any other position with engine running and all doors closed.	OFF	ON or OFF
	Auto Unlock/Shift	Function that unlocks all doors when the shift lever is moved to P from any other position while the ignition switch is ON.	ON	ON or OFF
	All Unlock/ Open-Close	Function that unlocks all doors when opening driver door within 10 seconds after turning the ignition switch to ON.	OFF	ON or OFF

(Continued)

System	Intelligent Tester II Display Content	Content	Default Setting	Available Setting
Wireless Door Lock	Wireless Control	ON/OFF of wireless door lock function.	ON	ON or OFF
	Hazard Answer Back	When lock switch on transmitter pressed, all hazard warning lights illuminate once. When unlock switch pressed, all hazard warning lights illuminate twice.	ON	ON or OFF
	Wireless Buzzer Resp	Function that makes wireless buzzer sound for answer back when transmitter lock/unlock switch pressed.	ON	ON or OFF
	Open Door Warning	If door is not completely closed and transmitter lock switch is pressed, this function sounds a buzzer for 10 seconds.	ON	ON or OFF
	Auto Lock Time	This function controls amount of time from unlocking doors to automatic re-locking function.	30 sec	30 sec, 60 sec or 120 sec
	Panic Function	This function operates the theft deterrent system when panic button is pressed and held for 0.8 seconds or more.	ON	ON or OFF
Power Back Door	PBD SW Operation	Function that turns power back door closer switch ON when the switch is pushed once or held down for 0.8 seconds.	0.8 sec	0.8 sec or ON
	PBD Buzzer*	This function makes the power back door buzzer sound when the power back door is operating.	ON	ON or OFF
	Wirels PBD SW Operation	Function that operates power back door when the transmitter switch is pressed in specified way.	0.8 sec	1 Oper, 2 Oper, 0.8 sec, OFF or 1 Motion
Power Window	Door Key P/W Up	Function that raises the drier and passenger power windows when, with the ignition switch off, a key is used to hold the driver door key cylinder to the lock position for more than 2.3 seconds.	ON	ON or OFF
	Door Key P/W Down	Function that lowers the drier and passenger power windows when, with the ignition switch off, a key is used to hold the driver door key cylinder to the unlock position for more than 2.3 seconds.	ON	ON or OFF
	Door Key Linked Back P/W Up	Function that raises the back door power window when, with the ignition switch off, a key is used to hold the driver door key cylinder to the lock position for more than 0.7 seconds.	ON	ON or OFF
	Door Key Linked Back P/W Down	Function that lowers the back door power window when, with the ignition switch off, a key is used to hold the driver door key cylinder to the unlock position for more than 0.7 seconds.	ON	ON or OFF

*: The warning buzzer that sounds when the power back door is operating cannot be customized (even if this function is set to “OFF”, the buzzer will still sound).

(Continued)

System	Intelligent Tester II Display Content	Content	Default Setting	Available Setting
Theft Deterrent	Warning by Horn	Function that allows the vehicle horn and theft deterrent horn to be used as warning devices.	ON	ON or OFF
	Entry Delay	Function that changes entry delay time (time before warning starts) for passive mode.	14 sec	0 sec, 14 sec or 30 sec
Tilt & Telescopic	Autoaway/Return Function	ON/OFF of the auto away/return function.	ON	ON or OFF
Sliding Roof	Door Key Related Operation	Function to select either tilt up or slide open for the manual sliding roof operation linked with power window, witch is activated by holding the driver door key in the unlock position for 3 seconds or more when the ignition switch is off.	SLIDE	TILT or SLIDE
	Door Key Related Open	Function to manually open the sliding roof linked with power window by holding the driver door key in the unlock position for 3 seconds or more when the ignition switch is off.	ON	ON or OFF
	Door Key Related Close	Function to manually close the sliding roof linked with power window by holding the driver door key in the lock position for 3 seconds or more when ignition switch is off.	ON	ON or OFF