■ LIGHT AUTO TURN-OFF SYSTEM

A light auto turn-off system is used to prevent the driver from leaving the exterior lights (headlights, taillights, parking lights, license plate lights) on.

- This system is controlled by the main body ECU.
- The exterior lights automatically turn off when all of the following conditions have been met:
  - The ignition switch is off or ACC.
  - The driver's door is opened and then closed.
  - The light control switch is in the TAIL, HEAD or AUTO position.

