■ FUNCTION OF MAIN COMPONENTS

Component		Function
Rear Display		● Displays DVD output images, video CD output images, adjustment screen, option screen, and diagnosis screen. ● Receives signals from remote control. ● Outputs audio signals to the wireless headphone in the form of infrared signals.
	RSE ECU	Processes audio and visual signals from the DVD player and outputs them.
	DVD Player	Outputs the audio and visual signals to the RSE ECU.
Remote Controller		Outputs various control signals for the RSES to the rear display in the form of infrared signals.
Headphone Terminal		The headphone terminal is used for connecting wired headphones.
Audio Head Unit (Models with JBL Branded Premium Audio System)		● Receives audio signals from the rear display and outputs them to the stereo amplifier. ● Turn on/off the child lock function (disables operation of the RSES through the remote control or panel buttons on the rear display) by the AUDIO CONTROL rotary knob.
Stereo Amplifier		Receives audio signals from the audio head unit and outputs them to the speakers.
Steering Pad Switch		The MODE button changes the audio source.