POWER WINDOW SYSTEM

■ DESCRIPTION

The power window system is standard equipment on all models.

- The power window system provides the following functions.

●: Equipped —: Not equipped

Function \ Door	Driver Door	Front Passenger Door	Rear Door RH/LH	Back Door
Manual Up-and-down	●	●	●	●
One-touch Auto Up-and-down	●	●	—	●
Jam Protection	●	●	—	●
Remote Control	—	●	●	—
Window Lock	—	●	●	—
Key Off Operation	●	●	●	●
Key-linked Up-and-down	●	●	—	●

- The power window system has the following functions:

Function	Outline
Manual Up-and-down	● This function causes the window to open or close while the power window switch is being pulled halfway up or pushed halfway down. The window stops as soon as the switch is released. ● The back door power window switch is located on the instrument panel.
One-touch Auto Up-and-down	The one-touch auto up-and-down function enables the window to be fully opened or closed at a touch of the power window switch.
Jam Protection	The jam protection function automatically stops the power window and moves it downward if a foreign object gets jammed in the window during power window close operation.
Remote Control	The power window master switch can control the up-and-down operations of the passenger windows.
Window Lock	Operation of the passenger windows is disabled when the window lock switch is pressed.
Key Off Operation	This function makes it possible to operate the power windows for approximately 43 seconds after the ignition switch is turned off, if either front door is not opened.
Key-linked Up-and-down	● The key in the driver door key cylinder is turned and maintained in the lock direction for 0.75 seconds or more, the main body ECU activates the power window motor to close the driver door and front passenger windows while the key is turned. Similarly, when the driver door is unlocked, turning and maintaining the key in the driver door key cylinder in the unlock direction for 0.75 seconds or more will cause the driver door and front passenger windows to be opened. ● The key in the back door is turned and maintained in the lock direction for 0.75 seconds or more, the main body ECU activates the power window motor to close the back door window while the key is turned. Similarly, when the back door is unlocked, turning and maintaining the back door key in the unlock direction for 0.75 seconds or more will cause the back door window to be opened.