■ FUNCTION

The theft deterrent system has the following functions:

Function	Outline
Alarm	When the theft deterrent system is switched to the alarm state, the warning items are operated and the alarm sounds for approximately 30 seconds.
Alarm Indicator	When the state of the theft deterrent system is switched to the armed preparation state or alarm state, the security indicator light is illuminated to inform the user. This indicator is also the engine immobiliser indicator, which blinks in the engine immobiliser set state.
Forced Door Lock	The main body ECU transmits a door lock signal to all the doors when all the following conditions are satisfied: ● The theft deterrent system is in the alarm state. ● There is no ignition key inserted in the ignition key cylinder. ● One of the front doors has been unlocked. The function stops when one of the following conditions is met: ● All doors are locked. ● The warning ends after approximately 30 seconds. ● The ignition key is inserted in the ignition key cylinder.
Panic Control	When the panic button of the transmitter is pressed, the main body ECU operates the alarm function.