Item		Function
Guidance	Voice Guidance	Provides voice guidance about the distance and the direction of travel to a destination point based on road conditions and vehicle speed.
	Next Turn Guidance	Provides guidance about the distance to the next turn and indicates the direction of the turn using an arrow.
	Motorway Mode Display	Displays the distance to the next junction and exit, or POIs in the area around a motorway exit.
	Motorway Exit or Junction Display	When the vehicle approaches an exit or junction, the motorway guidance screen will be displayed.
	Motorway Direction of Travel Display	Displays the direction of travel to take on the motorway.
	Real Motorway Junction Display	Displays the junction and signage in 3D in the area around a major junction while driving.
	Intersection Zoom-in Display	Zooms in the image when approaching an intersection.
	Turn List Display	Displays a turn list on the right side of the 2-screen display.
	Arrow (Turn-by-Turn) Display	Displays the direction of the next turn and the distance to the turn on the right side of the 2-screen display.
	Distance-to-destination Display	Displays the distance from the present location to the destination.
	Route Information Bar Display	Displays the following information: ● Street name of the current location ● Distance and travel time to the destination ● Distance to the destination and estimated time of arrival ● Distance to the destination and an arrow facing the destination (when off the route during the guidance)
Others	Map Coverage Information Display	Displays the map area that is stored on the micro SD card.

■ DIAGNOSIS

For details on the procedure required to enter the Service Menu screen, refer to the Repair Manual.