■ FUNCTION OF MAIN COMPONENTS

Component		Function
Ultrasonic Sensors (6)		Detect the distance between the vehicle and the obstacle.
Accessory Meter	Sonar ON/OFF Indicator Light	The sonar ON/OFF condition can be displayed.
	Indicator Lights (5)	• Show the location of the obstacle and the approximate distance between the vehicle and the obstacle. • Show an indication of a malfunctioning or frozen ultrasonic sensor to inform the driver.
	Buzzer	• Sounds to inform the driver according to the distance to the obstacle. • Sounds an indication of a malfunctioning or frozen ultrasonic sensor to inform the driver.
Clearance Sonar ECU		Judges the approximate distance between the vehicle and an obstacle based on signals from the ultrasonic sensors. Output signals are sent to the accessory meter.
SONAR Switch		Operating this switch allows the operation of the intuitive parking assist system to be enabled or disabled.
Combination Meter		Transmits a vehicle speed signal to the Clearance Sonar ECU.
Park/Neutral Position Switch		Transmits the shift position signal to the Clearance Sonar ECU.