MEMORY SYSTEM

■ DESCRIPTION

The memory system can store the driver seat, outside rear view mirror positions and tilt & telescopic position. Up to 2 memory positions can be stored in the system memory and recalled.

- The memory system is optional equipment on the Limited grade.
- Two positions can be saved using the memory switch.
- The Driver Seat ECU stores in its memory the four recordable adjustments of the seat (seat slide, front vertical, rear vertical and recline position). The Driver Seat ECU is built in to the power seat switch for the driver seat.
- The Mirror ECUs stores in its memory the outside rear view mirror position.
- The Tilt & Telescopic ECU stores in its memory the tilt & telescopic position.
- The Driver Seat ECU outputs a signal to each ECU to reproduce a stored position.
- The memory and recall conditions of this system are as follows.

Function	Condition
Memory	Memorizes the positions when all conditions below have been met and the 1 or 2 button is pushed while the “SET” button is pushed. • Ignition switch is ON. • Shift position is “P”. When the memory setting is completed, the buzzer in the power seat switch will sound for 0.5 seconds.
Recall	If the button 1 or 2 is pressed when all conditions have been met, it recalls the positions. • Ignition switch is ON. • Shift position is “P”. If the button 1 or 2 is pressed when all conditions have been met and within 30 seconds, it recalls the positions. • Ignition switch is OFF. • Driver door is opened.