3. Tire Pressure Warning System

In the tire pressure warning system, the following items have been changed.

Changed Item	'08 Tundra	'07 Tundra
Detection of vehicle speed (Judgment of vehicle running)	Vehicle Speed Signal (combination meter) and G-SW Signal from tire pressure warning valve and transmitter	Vehicle Speed Signal (combination meter)
The blinking of the tire pressure warning light between the registration of the ID code of the tire pressure warning valve and transmitter and the normal operation of the system	Turns ON after blinking for 1 minute	-
DTCs (Diagnostic Trouble Codes)	The following DTCs are added. • C2126/26: Transmitter ID not received in main mode • C2174/74: Vehicle speed signal malfunction	-

4. Back Power Window System

The position and type of the back power window switch have been changed as follows:

- Position: Left side of the instrument panel → Right side of the instrument panel
- Switch Type: Push type → Pull-up type