4. Brake Control System (4WD Models)

It is now possible to activate the VSC (Vehicle Stability Control) function in drive mode H4L.

○: Operates —: No Operates

Drive Mode		VSC OFF Switch	Brake Control VSC Function		VSC OFF Indicator Light	
			’09 Toyota Tundra	’08 Toyota Tundra	’09 Toyota Tundra	’08 Toyota Tundra
2WD		Normal Mode	○	○	—	—
		TRAC OFF Mode	○	○	—	—
		Auto LSD Mode	—	—	—	—
		VSC OFF Mode	—	—	Light ON	Light ON
4WD	4H	Normal Mode	○	—	—	Light ON
		VSC OFF Mode	—	—	Light ON	Light ON
	4L	Normal Mode	—	—	Light ON	Light ON
		VSC OFF Mode	—	—	Light ON	Light ON