■ FUNCTION OF MAIN COMPONENTS

Component		Function
Rear Display		• Displays DVD output images, video CD output images, adjustment screen, option screen, and diagnosis screen. • Receives signals from remote control. • Outputs audio signals to the wireless headphone in the form the infrared signals.
	RSE ECU	Processes audio and visual signals from the DVD player or auxiliary player (via the video terminal), and outputs them.
	DVD Player	Outputs the audio and visual signals to the RSE ECU.
Remote Control		Outputs various control signals for the RSES to the rear display in the form of infrared signals.
Video Terminal & Headphone Terminal		• The video terminal is used for connecting an auxiliary player. • The headphone terminal is used for connecting wired headphones.
Audio Head Unit (Models with JBL Branded Premium Audio System)		• Receives audio signals from the rear display and outputs them to the stereo amplifier. • Child lock function (disables operation of the RSES through the remote control or panel buttons on the rear display) on/off by the AUDIO CONTROL rotary knob.
Radio and Player with Display (Models with JBL Branded Navigation with AV System)		• Receives visual signals from the rear display and displays them. • Receives audio signals from the rear display and outputs them to the stereo amplifier. • Child lock function (disables operation of the RSES through the remote control or panel buttons on the rear display) on/off by the screen setting. • RSES on/off from front seat by the adjustment screen.
Stereo Amplifier		Receives audio signals from the audio head unit/audio visual unit and outputs them to the speakers.
Steering Pad Switch		The MODE button changes the audio source. (FM1 → FM2 → CD changer → AM → SAT1 → SAT2 → SAT3 → AUX jack → RSES)