INTUITIVE PARKING ASSIST SYSTEM

■ DESCRIPTION

The intuitive parking assist system informs the driver of the approximate distance between the sensors and the obstacles as well as their positions by displaying them on the accessory meter and by sounding a buzzer in the accessory meter.

- The intuitive parking assist system uses ultrasonic sensors to detect any obstacles at the corners, at the front, or the rear of the vehicle.
- The intuitive parking assist system is optional on all models.

■ OPERATING CONDITION

The operating condition of each ultrasonic sensor differs according to its installed position as shown in the table below:

×: Active -: Inactive

SONAR Switch	Ignition Switch	Shift Lever	Vehicle Speed	Sensor		
				Front Corner	Rear Corner	Back
OFF	OFF	Any Position	Not Applicable	-	-	-
ON	ON	P	Not Applicable	-	-	-
		Except P, R	6 mph (10 km/h) or higher	-	-	-
			6 mph (10 km/h) or less	×	-	-
		R	*	×	×	×

*: Vehicle speed does not affect the activation of the ultrasonic sensors.