CRUISE CONTROL SYSTEM

■DESCRIPTION

When the cruise control system is set to a desired vehicle speed, the throttle valve position is adjusted automatically to maintain the vehicle speed without the driver having to depress the accelerator pedal.

- This system effects control through the ETCS-i (Electronic Throttle Control System-intelligent).
- The cruise control system has the following equipment:

×: Standard OP: Option -: Not Available

Item		Regular Cab		Double Cab		CrewMax	
		1GR-FE	2UZ-FE/ 3UR-FE	1GR-FE	2UZ-FE/ 3UR-FE	2UZ-FE/3UR-FE	
Cruise Control System	With	×	×	×	×	×	×
	Without	OP	OP	-	-	-	-

■SYSTEM DIAGRAM

