■ MANUAL HEADLIGHT BEAM LEVEL CONTROL SYSTEM

1. General

The manual headlight beam level control system keeps the beam of the headlight adjusted to the appropriate level in accordance with the amount being towed and other factors. The headlight beam level can be adjusted from 0 to 5 by operating the headlight leveling switch.

