INTRODUCTION

OUTLINE OF NEW FEATURES

1. Brake

The Vehicle Stability Control (VSC) warning buzzer has been discontinued. When the VSC is being operated, the slip indicator light blinks.