POWER WINDOW SYSTEM

■ DESCRIPTION

- The power window system is available as follows:

×: Standard OP: Option -: Not Available

Item		Regular Cab	Double Cab	CrewMax
Window System	Power Windows (D-Auto Down)	×	×	×
	Manual Windows	OP	-	-

- The power window system has the following functions:

Function	Outline
Power Up-and-down (All Doors)	This function causes the window to open or close while the power window switch is being pulled halfway up or pushed halfway down. The window stops as soon as the switch is released.
One-touch Auto Down (Driver's Door)	The one-touch auto down function enables the window to be fully closed at a touch of the power window switch.
Remote Control (All Doors)	The power window master switch can control the up-and-down operations of windows.
Window Lock	Operation of the passenger window (regular cab) or 3 passenger windows (double cab or CrewMax) is disabled when the window lock switch is pressed.
Key Off Operation	This function makes it possible to operate the power windows for approximately 43 seconds after the ignition switch is turned off, if either front door is not opened.