■ FUNCTION OF MAIN COMPONENTS

Component		Function
Ultrasonic Sensor		Detects the distance between the vehicle and the obstacle.
Combination Meter Assembly		Transmits the vehicle speed signal to the clearance warning ECU.
	Multi-information Display	● Displays the location of the obstacle and the approximate distance between the vehicle and the obstacle. ● Informs the driver if the ultrasonic sensors malfunction, or if they freeze or become dirty.
	Buzzer	Sounds a buzzer to inform the driver according to the distance to the obstacle.*
Clearance Warning ECU		Judges the approximate distance between the vehicle and an obstacle based on signals from the ultrasonic sensors. Output signals are sent to the multi-information display.
Park/Neutral Position Switch		Transmits the shift position signal to the clearance warning ECU.
Clearance Sonar Switch Assembly		Operating this switch allows the operation of intuitive parking assist system to be enabled or disabled.

*: The buzzer is controlled by the clearance warning ECU.