■FUNCTION

1. General

The wireless door lock remote control system has the following functions:

Function	Outline
All Doors Lock	Pressing the lock button of the transmitter locks all doors and prohibits the electronic back door operation.
All Doors Unlock	Pressing the unlock button of the transmitter unlocks all doors and recognizes the electronic back door operation.
Automatic Lock Function	If none of the doors are opened within 30 seconds after being unlocked by the wireless door lock remote control, all the doors are locked again automatically.
Answer Back	The hazard light flashes once when locking, and flashes twice when unlocking to inform that the operation has been completed.
Transmitter Recognition Code Registration Function	● A maximum of 4 types of transmitter recognition codes can be registered in the wireless door control receiver. ● When 4 codes are already registered and a new code is registered, the oldest of the already registered codes is written over.
Customized Body Electronics	For details, see page BE-7.

2. Transmitter Recognition Code Registration Function

The table below shows the 4 special coded ID registration function modes through which up to 4 different codes can be registered. The codes are electronically registered (written and stored) in the EEPROM.
For details of the recognition code registration procedure, refer to the Yaris Repair Manual (Pub. No. RM00S1E).

Mode	Function
Rewrite Mode	Erases all previously registered codes and registers only the newly received codes.
Add Mode	Adds a newly received code while preserving any previously registered codes. This mode is used when adding a new transmitter. If the number of codes exceeds 4, the oldest registered code is erased first.
Confirm Mode	Confirms how many codes are currently registered. When adding a new code, this mode is used to check how many codes already exist. If the number of codes exceeds 4, the oldest registered code is erased first.
Prohibit Mode	Deletes all the registered codes and prohibits the wireless door lock function. This mode is used when the transmitter is lost.