■ DIAGNOSIS

If a malfunction occurs on the CAN communication line, the ECU that is connected to the CAN communication line stores the DTCs (Diagnostic Trouble Codes) in its memory.

- There are 2-digit DTCs and 5-digit DTCs for the CAN communication.
  - The 5-digit DTCs can be read by connecting an intelligent tester II to the DLC3.
  - The 2-digit DTCs can be read from the warning light on the combination meter by connecting the SST (09843-18040) to TC and CG terminals of the DLC3.

For details, see the Yaris Repair Manual (Pub. No. RM00S1E).