■CUSTOMIZED BODY ELECTRONICS SYSTEM

An intelligent tester II can change the specification of the systems or functions

System	Intelligent Tester II Display Content	Content	Default	Selection
Wireless Door Lock Remote Control System*1	Wireless Control	Function to turn ON or OFF of the wireless door lock.	ON	ON/OFF
	Auto Lock Time	To change the time until re-locking after unlocking with the wireless door lock function.	30 s	30 s/ 60 s
	Hazard Answer Back (Hazard answer back of the wireless)	Function to light up all turn signal lights once when pressing the transmitter lock button and twice when pressing the unlock button.	ON	ON/OFF
	Wireless Buzzer Resp*2	Function to turn ON or OFF of the wireless buzzer response function.	ON	ON/OFF
	Open Door Warn*2	Function to make the buzzer sound for 10 seconds if the door is open when locking with the wireless door lock.	ON	ON/OFF
Illuminated Entry System	Lighting Time	To change the lighting time after closing the door. (It will quickly fade out in case that the power source mode is selected to IG-ON.)	15 s	7.5 s/ 15 s/ 30 s
	I/L when ACC OFF	Function to illuminate the room light when the power source mode is selected from IG-ON to OFF.	ON	ON/OFF
	I/L ON W/Door Key Unlock	Function to illuminate the room light and engine switch illumination*2 when unlocking with the door key or transmitter.	ON	ON/OFF
Warning	Key Low Battery Warning*2 (Warn when the key battery becomes weak)	Setting a warning function for the first time when a key battery becomes weak.	ON	ON/OFF
	Key Remind Sound	To change the frequency of the key reminder buzzer.	NORMAL	NORMAL/ FAST/ SLOW/ 0 s
	Seat Belt Warning	Function to change the seat-belt warning buzzer.	D/P ON	D/P ON/ D ON/ P ON/ D/P OFF
Air Conditioner*3	Set Temperature Shift	To control with the shifted temperature against the display temperature.	NORMAL	+2 °C/ +1 °C/ NORMAL/ –1 °C/ –2 °C
	Air Inlet Mode	In case of turning the A/C ON when you desire to make the compartment cool down quickly, this is the function to change the mode automatically to recirculated mode.	MANUAL	MANUAL/ AUTO
	Compressor/Air Inlet DEF Operation	Function to turn the A/C ON automatically linking with the front DEF button when A/C OFF.	NORMAL	NORMAL/ LINK
	Evaporator Control	Function to set the evaporator control to the automatic position (AUTO) to save power or to the coldest position (MANUAL) to dehumidify the air and to prevent the windows fogging up.	AUTO	MANUAL/ AUTO

*1: Only for Models with Wireless Door Lock Remote Control System

*2: Only for Models with Smart Entry & Start System

*3: Only for Models with Automatic Air Conditioner

(Continued)

System	Intelligent Tester II Display Content	Contents	Default	Selection
Air Conditioner*3	FOOT/DEF Auto Mode	Function to turn the air flow to FOOT/DEF ON automatically when auto mode is ON.	ON	ON/OFF
	FOOT/DEF Automatic Blow Up Function	Function to switch the blower level up automatically when the defroster is ON.	ON	ON/OFF
	Ambient Temperature Shift	To control with the shifted ambient temperature against the display ambient temperature.	NORMAL	+3 °C/ +2 °C/ +1 °C/ NORMAL/ –1 °C/ –2 °C/ –3 °C
Multi-information Display*4	Units By Region	To change the unit of the display.	KM/L	ML/G UK/ KM/L
Smart Entry & Start System*2	Park Wait Time	Setting a wait time to permit opening a door after it being locked.	3.0 s	1.0 s/ 2.0 s/ 3.0 s/ 5.5 s
	Back Door Opening Operation	Function to open a trunk when the key is detected inside the trunk.	Long	Long/ Twice/ OFF

*2: Only for Models with Smart Entry & Start System
*3: Only for Models with Automatic Air Conditioner
*4: Only for Europe Models