Component Locations

LH drive



RH drive


EACV
Troubleshooting, page 6-62
CONTROL BOX
page 6-6
POWER STEERING OIL PRESSURE SWITCH
Troubleshooting, page 6-70
IGNITER UNIT
Troubleshooting, page 6-54
Test, section 16
THROTTLE ANGLE SENSOR
Troubleshooting, page 6-42
INTAKE AIR TEMPERATURE (TA) SENSOR
Troubleshooting, page 6-48
TDC SENSOR
Troubleshooting, page 6-44
INJECTOR RESISTOR
Test, page 6-80
EGR VALVE LIFT SENSOR (KE)
Troubleshooting, page 6-102
REAR OXYGEN (O2) SENSOR (KQ)
Troubleshooting, page 6-28
BYPASS CONTROL DIAPHRAGM
Troubleshooting, page 6-93
EGR VALVE (KE)
Troubleshooting, page 6-102
CRANK/CYL SENSOR
Troubleshooting, page 6-36
FRONT OXYGEN (O2) SENSOR (KQ)
Troubleshooting, page 6-28

Component Locations

LH drive



MIXTURE COMPENSATION RESISTER (KB, KF)
Troubleshooting, page 6-30

ELECTRONIC CONTROL UNIT (ECU)
Troubleshooting, page 6-25



ATMOSPHERIC PRESSURE (PA) SENSOR
Troubleshooting, page 6-52

MAIN RELAY
Test, page 6-86

IMA SENSOR (KB, KF)
Troubleshooting, page 6-50

RH drive



MAIN RELAY
Test, page 6-86

ATMOSPHERIC PRESSURE (PA) SENSOR
Troubleshooting, page 6-52

IMA SENSOR (KB, KF)
Troubleshooting, page 6-50



MIXTURE COMPENSATION RESISTER (KB, KF)
Troubleshooting, page 6-30

ELECTRONIC CONTROL UNIT (ECU)
Troubleshooting, page 6-25


DASHPOT DIAPHRAGM
Test, page 6-92
FAST IDLE VALVE
Inspection, page 6-74
THROTTLE BODY
Inspection, page 11-81
Disassembly, page 11-82
AIR CLEANER ELEMENT
Replace every 2 years or
40,000 km (24,000 miles),
whichever comes first.
RESONATOR
THROTTLE CABLE
Inspection/Adjustment, page 6-89
Replacement, page 6-89
AIR INTAKE TUBE
FUEL GAUGE SENDING UNIT
Test, section 23
CHARCOAL CANISTER
Test, page 6-107
TWO-WAY VALVE
Test, page 6-108
MAINTENANCE ACCESS COVER
FUEL FEED
PIPE
FUEL FILTER
Replacement, page 6-83
FUEL TANK
Replacement,
page 6-87
PRESSURE REGULATOR
Test, page 6-80
Replacement, page 6-81
FUEL FILLER
CAP
FUEL INJECTOR
Test, page 6-77
Replacement, page 6-78
FUEL PUMP
Test, page 6-84
Replacement, page 6-85
FUEL CUT-OFF VALVE
FUEL VAPOR PIPE
FUEL RETURN PIPE