AUTOMATIC TRANSMISSION (3UZ–FE)

HOW TO PROCEED WITH TROUBLESHOOTING

DI87U–01

Items inside ▱ are titles of pages in this manual, with the page number indicated in the bottom portion. See the indicated pages for detailed explanations.