
(IG)
(BAT)
10A
IG1 D
NO. 1
30A
S/HTR D
2
33 3D
15 3D
P56(A), P57(B), P58(C)
Air Conditioning Amplifier Assembly
LOUT
24 C
R
37 PX1
y1
Seat Back Climate
Control Blower LH
LA–B
LA–R
6 Xw1
G
3
1
4
P
LG
W–B
12 Xw1
5 yw1
1 yw1
6 yw1
LG
P
LG
W–B
2 Xw1
7
6
5
4
8
1
w6
Seat Cushion Climate Control
Blower Assembly LH
P
W–B
B
7 Xw1
4
2
11
w13
No. 11
Junction Connector
12
6
7
9
LA–R
LA–R
P
G
G
W–B
5 Xw1
W–B
W–B
G
G
P


P56(A), P57(B), P58(C)
Air Conditioning Amplifier Assembly
TSL
SG–5
17 A
8 B
B
LG
60 PX1
38 PX1
B
LG
11 Xw1
8 Xw1
V
SB
(BAT)
100A
J/B
D–ALT
1 2B
W
(BAT)
15A
IG1 D
NO. 7
2
IG1 D
NO. 1
Relay
IG1 D
NO. 3
Relay
1 3F
6 3B
9 3D
W
W–B
LA–R
SB
V
LA–R
W–B
W–B
G
G
G
G
P
P
PC


P56(A), P57(B), P58(C)
Air Conditioning Amplifier Assembly
SHD+
15 A
P
59 PX1
P
10 Xw1
R
w5
Seat Heater LH (Front Seat Cushion Heater Assembly LH)
Seat Back
Back Heater
Seat Cushion
Cushion Heater
w9
Seat Heater Control Sub–Assembly LH
4
5
4
1
2
6
3
12
10
7
1
8
3
SB
V
W–B
L
P
G
G
P
4 Xw1
W
W–B
W–B
W–B
G
G
P
XA


P56(A), P57(B), P58(C)
Air Conditioning Amplifier Assembly
ROUT
23 C
(BAT)
100A
J/B
P–ALT
1 B
A70(B)
Fusible Link Block
Assembly No. 1
B
(BAT)
15A
IG1 P
NO. 6
2
IG1 P
NO. 1
Relay
IG1 P
NO. 3
Relay
1 4F
9 4A
10 4D
B
W–B
LA–R
7 Xv2
x1
Seat Back Climate
Control Blower RH
3
1
4
P
LG
W–B
5 xv1
1 xv1
6 xv1
P
LG
W–B
6
5
4
1
B
BE
60 PX3
BE
12 Xv2
LG
7
8
W–B
v6
Seat Cushion Climate Control
Blower Assembly RH
W–B
PG


P56(A), P57(B), P58(C)
Air Conditioning Amplifier Assembly
CANH
CANL
TSR
SG–6
11 C
12 C
18 A
9 A
L
W
G
R
2
13
P107
No. 1 CAN
Junction Connector
1
12
37 PX3
59 PX3
R
W
P
V
9 PX2
20 PX2
11 Xv2
8 Xv2
V
W
V
SB
v5
Seat Heater RH
(Front Seat Cushion Heater Assembly RH)
Seat Back
Back Heater
Seat Cushion
Cushion Heater
5
4
1
2
6
3
W–B
L
P
W
4 Xv2
W–B
W–B
W–B
W–B
W–B
W
V
XB


P56(A), P57(B), P58(C)
Air Conditioning Amplifier Assembly
SHP+
16 A
L
38 PX3
L
10 Xv2
R
4
v9
Seat Heater Control Sub–Assembly RH
12
10
7
8
1
3
L
P
W
G
G
P
6
7
12
v13
No. 10
Junction Connector
9
11
2
4
W–B
W–B
G
5 Xv2
W–B
W–B
(IG)
(BAT)
10A
IG1 P
NO. 2
30A
S/HTR P
2
2
11 4D
15 4D
LA–B
LA–R
LA–B
2 Xv2
6 Xv2
P
G
W
W
V
V


P43(A), P46(C)
Radio Receiver Assembly
TX1+
TX1–
CANL
CANH
CNL1
CNH1
(BAT)
(ACC)
15A
RADIO
NO. 1
10A
ACC P
NO. 1
P42(A)
Multi–Display
TX+
TX–
P116
No. 4 CAN
Junction Connector
P90
No. 5
Junction Connector
P59
Network Gateway ECU
CA3L
CA3H
CA5L
CA5H
P69
Remote Operation
Controller Assembly
+B
ACC
MO+
MO–
GND
PX4
PX2
X85(D), X86(E)
No. 10 CAN
Junction Connector
X88(A), X93(E)
No. 11 CAN
Junction Connector
PD

A70



P42
Black



90980-12554

P43
White



82824-52380

P46
White



90980-12761

P56
White



82824-52380

P57
White



90980-12761

P58
White



90980-12760

P59
Black



90980-12912

P69
Black



90980-12361

P90
White



90980-12B54

P107
White



90980-12B54

P116
Black



90980-12B54

X85
White



90980-12827

X86
White



90980-12827

X88
White



90980-12827

X93
White



90980-12827

v5
Black



90980-10796

v6
White



90980-12735

v9
White



90980-12812

v13
White



90980-12346

w5
Black



90980-10796

w6
White



90980-12735

w9
White



90980-12812

w13
White



90980-12346

x1
White



90980-12733

y1
White



90980-12733

2B



3B
White



90980-12A48

3D
White



90980-12944

3F
White



90980-12756

4A
White



90980-12943

4B
White



90980-12A48

4D
White



90980-12944

4F
Gray



90980-12756

PX1
Gray



90980-12B20



90980-12B19

PX2
White



90980-12372



90980-12371

PX3
Gray



90980-12B20



90980-12B19

PX4
White



90980-12368



90980-12367

Xv2
White



90980-12374



90980-12373



90980-12374

90980-12373



90980-12376

90980-12375



90980-12376

90980-12375