
D87
D92
D89
D85
D86
D91
D90
D
D
D95
D88
D83
D84
D82
D81
D94
D93
D80

D 80 Cam Timing Oil Control Solenoid Assembly (Bank 2 Intake Side)
D 81 Cam Timing Oil Control Solenoid Assembly (Bank 1 Intake Side)
D 82 Cam Timing Oil Control Solenoid Assembly (Bank 1 Exhaust Side)
D 83 Cam Timing Oil Control Solenoid Assembly (Bank 2 Exhaust Side)
D 84 Intake Mass Air Flow Meter Sub-Assembly
D 85 Fuel Pressure Sensor (Low Pressure Side)
D 86 Fuel Pressure Sensor (High Pressure Side)
D 87 Air Fuel Ratio Sensor (Bank 1 Sensor 1)
D 88 Air Fuel Ratio Sensor (Bank 2 Sensor 1)
D 89 Air Fuel Ratio Sensor (Bank 1 Sensor 2)
D 90 Air Fuel Ratio Sensor (Bank 2 Sensor 2)
D 91 E.F.I. Engine Coolant Temperature Sensor
D 92 Fuel Pump Assembly
D 93 Water Inlet with Thermostat Sub-Assembly
D 94 Engine Oil Pressure Switch Assembly
D 95 Starter Assembly

D80
Black



90980-11875

D81
Black



90980-11875

D82
Black



90980-11875

D83
Black



90980-11875

D84
Black



90980-12A85

D85
Black



90980-12A19

D86
Black



90980-12A19

D87
Black

90980-10869

D88
Black

90980-10869

D89
Black

90980-10869

D90
Black

90980-10869

D91
Black

90980-12416

D92
Black



90980-12747

D93
Black

90980-12572

D94
Black

90980-11363

D95

82675-50110