
∗ 7 : Before Aug. 2017 Production
∗ 8 : From Aug. 2017 Production
A31
Accelerator Pedal Sensor Assembly
VPA
EPA
VCPA
VCP2
EPA2
VPA2
E47(A)
Center Airbag Sensor Assembly
Yaw Rate Sensor
CANH
CANL
A38(A), C53(E)
ECM
ECCS
CANN
CANP
CAN–
A74(C)
Transmission Control ECU Assembly
PA
C
B
A
EE1
EA3
CA3
E161
Junction Connector
A37(A), C52(C)
Junction Connector
MPX1
MPX2
TX+
TX–
E147
Meter Mirror Sub–Assembly


(IG)
(ACC)
(IG)
(IG)
10A BKUP LP
10A ECU–ACC NO. 1
10A N/ST SW
10A ECU–IG NO. 2
A75 Diode
A24(A) Skid Control ECU with Actuator Assembly
Front Speed Sensors
Rear Speed Sensors
FL+
FL–
FR+
FR–
CANL
CANH
RL+
RL–
RR+
RR–
A49(A), A50(B) Short Connector
A38(A), C53(E) ECM
E118(B) Main Body ECU
C19 Park/Neutral Position Switch
RB
RL
IG
A
B
C
PA
P
R
N
D
E158 Junction Connector
E131 Steering Sensor
CA4
EA1


(IG)
5A
ECU–IG
NO. 6
10A
ECU–IG
NO. 3
10A
ECU–IG
NO. 2
∗ 6 : w/ Pre–Crash Safety System Heater
A67
Millimeter Wave
Radar Sensor Assembly
R26
Forward Recognition with
Heater Hood Sub–Assembly
R15
Forward Recognition Camera
E159
Junction Connector
E164
Junction Connector
E138
Driving Support
ECU Assembly
CA1N
CA1P
CA2H
CA2L
IG1
HTR
IGB
STPV
GND
CANH
CANL
SPSW
RE1
RE2
EA2
E1
E2


(IG)
15A
STRG HTR
2
1
L
P
B
P
77 EA1
L
P
W–B
E102(A), E124(B), z63(C), z64(D)
Spiral Cable Sub–Assembly
E137
Network Gateway ECU
9 A
4 B
2 B
LDA
BHT
EHT
2 D
4 C
1 C
IG
GND
LDA
M+
M–
M
z63(C)
Steering Vibration & Heater Control
(Steering Wheel Assembly)
z64(D)
Switch Wire
B
P
50 EA2
49 EA2
B
P
5
15
E164
Junction Connector
CA5L
CA5H
CA4L
CA4H
16
15
17
18
B
SB
W
L
B
SB
G
B
BR
W
W
L
BE
W
G
B
BR
W
W–B
BE
W
E1


(BAT)
10A
MPX–B
NO. 2
(IG)
5A
METER
46 EA1
49
BE
E120(A), E121(B)
Combination Meter Assembly
21
22
B
IG+
Power
Supply
Circuit
+B
IG+
Master
LDA
TFT
Buzzer
SUB
IG
One Step
Dim
SUB
SUB
CAN
INPUT
MSCL
MSCH
EL
ER
CANH
CANL
38
37
10
9
39
40
G
L
L
B
BE
W
BR
W
12
1
E163
Junction
Connector
17
6
11
12
CR
TL
EL
TR
Turn Signal Switch
L
L'
N
R'
R
E14
Headlight Dimmer
Switch Assembly
15
25 EA3
BR
BR
G
B
BR
W
W–B
BE
W
E1


E120(A), E121(B)
Combination Meter Assembly
ET
MSTI
MSM+
HZSW
20 A
3 B
2 B
11 B
BR
W
BR
BR
BR
W
BR
B
L
P
5 FE1
P
3 A
12 A
2 A
11 A
10 A
EAU
DIST
ECC
+DP2
+DP
E102(A), z65(E)
Spiral Cable Sub-Assembly
8 E
4 E
7 E
3 E
2 E
67 EA3
BR
19 A
14 B
A37(A), C52(B)
Junction Connector
BR
C1
Steering Switch LH
Lane
Departure
Alert
Left
Enter
Up
Top
Down
Back
Right
Steering Switch RH
z65(E)
Steering Pad Switch Assembly
9 B
HAZ
F77(B)
Multi-Media Module Receiver Assembly

A 24
Black



A 31
Black



A 37
Blue



A 38
Black



A 49
Gray

A 50
Gray



A 67
Black



A 74
White



A 75
Gray



C 19
Gray



C 52
Blue



C 53
Black



E 14
White



E 47
Yellow



E102
Black



E118
White



E120
Black



E121
Black



E124
Black



E131
White



E137
Black



E138
White



E147
White



E158
White



E159
White



E161
White



E163
Black



E164
White



F 77
White



R 15
Gray



R 26
Black



z 63
White



z 64
Black



z 65
Black



2H
White



2I
White



2J
White



3C
White



CA3
White



CA4
White




EA1
White


EA2
White
Gray


EA3
White
EE1
White
FE1
White
RE1
White
RE2
Blue