Position of Parts in Engine Compartment

[LHD: 22R]

*1: Europe
*2: Ex. Europe

