
BLOWER SWITCHES

Front Heater Blower Switch

INSPECTION OF BLOWER SWITCH

INSPECT SWITCH CONTINUITY



O-8-2


Terminal / Switch position	1	2	3	4	5	6
OFF						
I		○	○	○		
II		○	○		○	
III		○	○			○
IV (HI)	○	○	○			

If continuity is not as specified, replace the switch.

Rear Heater Blower Switch

INSPECTION OF BLOWER SWITCH

INSPECT SWITCH CONTINUITY



H-4-2

Terminal / Switch position	1	2	3	4
HI	○	○		○
OFF				
LO		○	○	○

If continuity is not as specified, replace the switch.