OPERATION


IG034–01

The function of the ignition system is to distribute spark to the cylinders at appropriate timing in accordance with the piston position.

PREPARATION

SST (SPECIAL SERVICE TOOLS)

IG00R–02

	09155–16100 Spark Plug Wrench	

RECOMMENDED TOOLS

IG00S–01

	09082–00015 TOYOTA Electrical Tester	
	09200–00010 Engine Adjust Kit	

EQUIPMENT

IG00T–02

Megger insulation resistancemeter	
Spark plug cleaner	
Torque wrench	