
CO0RL–01

REMOVAL

HINT:

Removal of the thermostat would have an adverse effect, causing a lowering of cooling efficiency. Do not remove the thermostat, even if the engine tends to overheat.

1. DRAIN ENGINE COOLANT



2. REMOVE THE WATER INLET AND THERMOSTAT

(a) Remove the 3 bolts and water inlet.
(b) Remove the thermostat.
(c) Remove the gasket from the thermostat.