LU0EU–01

REASSEMBLY



1. INSTALL RELIEF VALVE

(a) Insert the relief valve and spring into the installation hole of the timing gear case.

(b) Install a new gasket and the plug.
Torque: 42 N·m (425 kgf·cm, 31 ft·lbf)



2. INSTALL DRIVEN ROTOR

Place the driven rotor into the timing gear case with the marks facing the timing gear case side.