

LU0F3–01

INSTALLATION

1. **INSTALL OIL NOZZLES AND CHECK VALVES**

(a) Align the pin of the nozzle with the pin hole of the cylinder block.

(b) Install the oil nozzle with the check valve. Install the 6 oil nozzles and 6 check valves.

Torque: 27 N·m (275 kgf·cm, 20 ft·lbf)

2. **INSTALL OIL PAN (See page LU–13)**