ST0FB–01

REASSEMBLY

Reassembly is in the reverse order of disassembly.

(See page ST–9)

HINT:

At the time of assembly, please refer to the following items.

Use high–temperature grease to lubricate the bearing and gears when assembling the starter.