DI1IP–08

DTC	P1335/13	Crankshaft Position Sensor Circuit Malfunction (During engine running)

CIRCUIT DESCRIPTION

Refer to DTC P0335/12,13 on page DI–44.

DTC No.	DTC Detection Condition	Trouble Area
P1335/13	No crankshaft position sensor signal to engine ECU with engine speed 1,000 rpm or more	• Open or short in crankshaft position sensor circuit • Crankshaft position sensor • Signal plate • Engine ECU

WIRING DIAGRAM

Refer to DTC P0335/12,13 on page DI–44.

INSPECTION PROCEDURE

Refer to DTC P0335/12,13 on page DI–44.