ED05N–01

REMOVAL

1. DISCONNECT NO.2 AIR TUBE

2. REMOVE THROTTLE BODY

(a) Disconnect the throttle control motor connector and throttle full switch connector.

(b) Remove the 2 bolts and 2 nuts, throttle body and gasket.
Torque: 19.6 N·m (200 kgf·cm, 14 ft·lbf)

(c) Remove the bolts, intake heater and gasket.
Torque: 7.5 N·m (80 kgf·cm, 66 in.·lbf)